


# HOP series

This is a special tool used to remove oil seals.

Oil seals (up to an outer diameter size of 150) can be removed quickly and easily from motorcycles, compact cars, and large-sized vehicles. If a roller fulcrum is used, oil seals can be removed without scratching the housing.

Oil seals can be removed easily, without scratching the casing.

A simple construction and carefully tested materials assure outstanding durability.



Sizes				
Model	A	B	C	D
HOP-2060	70mm	20mm	260mm	14
HOP-2090	100mm	20mm	285mm	14
HOP-5150B	200mm	45mm	340mm	16

