

STEERING WHEEL PULLER

SP-85A

This powerful puller is used to remove the steering wheel. Built-in bearing (steel balls) makes removal extremely easy!

Two- and three-fitting types supported.

Applicability: from mini-sized motor vehicles to medium duty trucks.

* Not usable for steering wheel units with sizes out of the applicable range, such as those of vehicles equipped with airbags.

* The specified bolt (overall length: 80 - 90 mm, hardness: 7T min.) and a washer that fits the service tap (M8 x P1.25, M10 x P1.25 are included in the set) should be prepared before removing the steering wheel unit.

* Impact wrenches may not be used, and shock should not be applied using a hammer or other tool.



Part names and code numbers

